



ProMarine
s u p p l i e s

Let's Make a Bottle Cap Tray!

with Pro Marine Supplies

Materials

1. Serving Tray (Any Size)
2. Pro Marine Supplies Tabletop Epoxy Resin
3. Bottle Caps
4. Super Glue (E6000)
5. Stirring Stick
6. (4) Utility Measuring Cups (sold at most hardware stores)
7. Hand Torch
8. Gloves
9. Rubbing Alcohol
10. Paper Towels
11. Foam Brush
12. Hot Glue

Making the Tray

Step-By-Step Instructions

1. Seal the Bottle Caps using Hot Glue and let dry.
2. Clean off the surface of the wood with Alcohol and a Paper Towel.
3. Glue Sealed Bottle Caps to Tray.
4. Tape off the areas you don't want the Epoxy mixture to run.
5. Put on your Gloves and mix 8 oz. (4 oz. part A, 4 oz. Part B) of Epoxy-Resin. Follow Pro Marine Supplies Mixing Instructions. This will be your "Seal Coat".
6. Pour your Seal Coat over the board and spread with a foam brush.
7. Torch out any air bubbles.
8. Let your Seal Coat dry (~4-6 hours)
9. Using new containers, mix equal parts Resin and Hardener (Part A and Part B). Follow Pro Marine Supplies Mixing Instructions. This will be your "Flood Coat".
10. Pour your thoroughly mixed Epoxy-Resin over the surface of the board and spread with foam brush.
11. Torch every 3-5 minutes to remove surfaced air bubbles, until bubbles disappear.
12. Let the Epoxy-Resin cure for ~72 hours in a clean, dust free environment at 75-80°F.
13. Place anywhere inside your home!